SPRINKLER IRRIGATION SYSTEM DESIGN

NAME				D,	ATE			_ PRI	EPAREI	O BY_				
SWCD				COUNTY					ENGR	. JOB	CLASS _			
INVENTORY														
Total Acres			Crop A	cres			_ Climatic	Area						
Water Source		Ar	nt. Avaīlab	le	gp	m,	ac	ere ft _		_ Season	al variation		_ gpm to gpm	
Power Source, El	ectric	vo	lts,	_ phase.	Internal	combus	stion engi	ne	Fue	el type .	Ot	her		
SOILS DATA														
USDA limiting soil series			Total	Available (in/ft)	WHC			Depth to					Maxîmum întake rate (în/hr)	
50" 50"		0-1	1-2	2-3			Inhibiting 4—5 (ft		layer	Wa	ter table (ft)		()	
WEIGHTED CO	NSUMPTI	VE USE												
	Crops			Acres (A)				June			July		August	
					ACIDS (A)			Sunv			- July		, to 9 to c	
IRRIGATION R	EQUIREM	ENTS												
			Root		Total AWHC			ss		a×. Net		eak	Max. Freq.	
С	rops		Zone Depth (Point (%AWHC)		Replacement (inches)			Daily C.V.	at Peak C.U. at Max. Net	
DESIGN DATA														
Based on weighte	ed consum	ptive use,		% Eff.,		М	PH winds,			_ Wind F	actor			
						Peak D	aily	F	requenc	у				
Application		· · · · · · · · · · · · · · · · · · ·	_	C.U. (Weight	*	(requency F) (Days)		System Requi		·			
Net (D)		+ '	iross							fioral dbi	וו) (ע)	gpm/ac.		
WOXIIII			1											

 $Q = \frac{453 \text{ A D}}{\text{F H Eff.}} \text{ system capacity}$

H = Total operating hours/day. Use 23 hours.

^{*} Use controlling weighted monthly consumptive use in Washington Irrigation Guide and determine daily consumptive use from Table 5, NRCS Technical Release 21, Irrigation Water Requirements.

SPRINKLER SYSTEM DESI	GN

Nozzla Spacina	(s.)	lateral	Spacina o	n Mainline	(s)	Min wetted a	lia –		(\$ _m)	41
Nozzie Spacing	(3[,	, Luterai	spacing u	ii Mullillie	(3m),	Milli, Welled C	iid.=		$\frac{(\$_m)}{\text{(wind factor)}} = \underline{\hspace{1cm}}$	16-
Sprinkler Head,	make		Model		nozzle size	· c	SPM	PSI	wetted dia	
Application rate	īn/hr	, Applic.	time	hrs/set. No	et Applic.=	(rate, in,	/hr) X _	(eff) X	(hrs/set)=	īn.
Max. Irr. Cycle=	(Net App (Peak Daily	olic.) =	day	ys. Min. No. L	aterals= (Max	(No.	Lateral Sets e) (Move) rs/day) =	
Designed Latera	s: No	, Dīa	, Type	, Move	es/day	Sys: Cap.=(n	o. of nozz	z) X (gpn	n/nozz)=	_gpm.
LATERAL DES	SIGN									
Allowable Friction	n Loss = 0.2	X (nozz.	psi	+ elev.	· 31)= _	psi.	Actual Fri	ction Loss (worst	condition)	_ psi.
Pressure require	Pressure require at the Mainline: P = (nozz. psi) + $3/4$ X (lat. fric. psi $\pm \frac{\text{elev.}}{2.31}$) = psi									
MAINLINE DE	SIGN									
Mainline: mater	īal	·	psi rating	-	other d	escription, PIP	, IPS, SDR	R. GATE, CLASS, et	с	
Friction factor L	sed		Mannings	"n" fectors:	olastic under (6" = 0.010, o	ver 6" =	0.009, steel = 0.0	012, asb. cem. = 0.0	1
Desirable mainlin	ne velocities a	re 5 fps	or less (r	equired on PVI	C and AC pipe	·).				
Station From To	Diameter of Pipe	Flow (gpm)	Velocity (fps)	Distance	Friction Loss per 1000'	Friction Loss this Section (ft)	Accum. Friction Loss	ı	Remarks	
	_									
										\dashv
L	_						l l			
DETERMINATION	ON OF TOT	AL DYN	AMIC HE	'AD						
Pressure required at Main				. psi	f	t				
Friction loss in Main				. psi	f	't				
Elevation rise/fall				. psi	f	. ft				
Lift (water surface to pump)				psi	f	_ ft				
Column Loss				. psi	f	_ ft				
Miscellaneous Loss				. psi	f	_ ft				
Total (TDH)				. psi	1	. TDH must be in feet for horsepower equation				

BHP = -	(TDH) X (GPM 3960 X (Pump Eff.)	=		HP	
Pump cur	ve data attached.	yes ()	по () If not supplied, NRCS will assume 70% efficience	:у.
Bill of mo	nterial attached.	yes ()	no ()	

HORSEPOWER REQUIREMENTS

	Needed	Not Needed	Location	Size	Construction Check, Installed
Expansion Couplers					
Reducers					
Anchors					
Thrustblocks					
Bends					
Tees					
Outlets					
Surge Chamber					
Drain Valves					
Check Valves					
Pressure Relief Valves					
Aîr-Vacuum Release Valves					
Pipe Supports					
Corrosion Protection					
Other:					

Attach any special drawing	
COMMENTS:	
JUMMENTS.	_

LOCATION AND LAYOUT MAP Show: Location of acres not sprinkled. Direction of prevailing wind. Elevations (contour preferable). Stations on mainline in feet or alphabetical notation. Fump location. Mainline location HIII Lateral layout \underline{W} = wheel line \underline{H} = hand move S = solid set Direction of lateral move. North Arrow Location of nearest section corner. Scale _____ Township ____ Range _____ Section ____ SYSTEM DESIGNED BY: (Organization) ______(Signature) ______(Date) _____ (NRCS ONLY) Reviewed by: _______Date _____ Approved by: ______ Date _____ REMARKS _